PLEASE KEEP WITH THE DART UNIT

DART SYSTEM SETUP

- 1. Once screen is set up, place the MAIN unit with the Projector and the Computer about 12 feet from the Screen with the FRONT facing the Screen.
- 2. Remove the Front and Rear covers.
- 3. Retrieve the power cord from the unit and the extension cord from the Screen Box.
- 4. Plug in the cords, remove the keyboard and mouse and mouse pad from inside the unit and place on top of the unit. Please use the mouse pad.
- 5. Turn on the Power at the power strip (on the top or on the side of strip).
- 6. Use the Remote Control to turn on the Projector. Once you have an image on the screen, move the main unit forwards or backwards to adjust the image to fill the HEIGHT of the screen, NOT the width.
- 7. Turn the Computer on by pressing the large button on the right-hand side of the front of the Computer.
- 8. When the "Dart System 300" image appears, press any key.
- 9. Select Animal Scenes.
- 10. Select or type in the time amount (up to 999).
- 11. Input two player names (anything).
- 12. Follow the prompts to sight in the two guns. Once you have a gun sighted on one side it's best to use it only on that side until you re-sight it in. There are slight differences in each gun depending on the side it is sighted on).
- 13. The DART System will run for quite awhile then come to point where it will just stop responding. Hit escape and re-setup system. It happens periodically.

Plan on a trial run of the system prior to your event!

PLEASE DO NOT ATTEMPT TO CHANGE ANY SETTINGS INCLUDING ADJUSTING THE DETECTOR OR THE CAMERA!

If you notice any minor problems with the unit, email me @ <u>TBUNTY@HOTMAIL.COM</u>. If you have a major show-stopper, call me at 717-309-5336 and I will try to assist you as much as possible.

Symptom:

Mouse sticks in upper right hand corner or guns seem to be firing on their own with no one near them.

Problem:

TOO MUCH SUNLIGHT OR ANY STRONG LIGHT IS GETTING TO THE DETECTOR.

Solutions:

Darken the room, rotate the unit setup, block the sunlight. The DART System DOES NOT work well in OUTDOOR settings.